

Multi-Lab

Termohigrometru model 93640

Prezentare

- ▶ Termohigrometru portabil, compact care poate asigura monitorizarea temperaturii si umiditatii relative in orice loc.
- ▶ Sensorul capacitiv incorporat, asigura masurarea cu mare acuratete a umiditatii mediului, in domeniul 5...95% r.h., cu o rezolutie de 0.1%.
- ▶ Tastatura de cauciuc are rol de protectie impotriva prafului si a substantelor varsate accidental
- ▶ Un capac sinterizat poate fi aplicat senzorului pentru asigurarea protectiei in medii cu praf. Daca se doreste obtinerea unui raspuns mai rapid, se poate scoate capacul sinterizat.
- ▶ Constructia permite operarea cu o singura mana, carcasa compacta se potriveste formei mainii.
- ▶ Garantie 12 / 24 luni (optional)
- ▶ Detine **Aprobare de Model BRML**



The HI-93640 Thermo-hygrometer is a compact and robust portable meter with a sintered metal filter protected humidity sensor fixed to the top of the meter.

This meter is designed to be used in general manufacturing and farming conditions and includes features which will be a real benefit in those applications. The sintered metal filter provides protection to the sensor for when measuring powder materials such and grain while the keyboard switches are rubber protected, and the clear LCD display is sealed behind a clear plastic window.

Relative humidity readings are displayed directly on the LCD display, and the operator can also choose to read temperature in either Centigrade or Fahrenheit. A flexible 'go-anywhere' meter.

Caracteristici tehnice

Domeniu de masurare	Umiditate relativa: 5.0 ... 95.0%
Range	Temperatura: 0.0 ... 60.0°C
Rezolutie	Umiditate relativa: 0.1%
Resolution	Temperatura: 0.1°C
Acuratete	± 2% r.h.
Accuracy	± 0.4°C
Baterii/ Timp de viata	1 x 9V / aprox. 100 ore de functionare continua
Battery Type / Life	
Conditii ambientale	0... 50°C; RH max. 98%, fara condens
Environment	
Dimensiuni	190 x 80 x 38 mm
Dimensions	
Greutate	320 g
Weight	
Preț EURO fara TVA	Termohigrometru cu senzori incorporati, livrat impreuna cu capacul de protectie si instructiuni de utilizare
*SUNATI	
optional	Verificarea metrologica umiditate
Garantie	12 sau 24 luni (Optional)